

PPE & ACCESSORIES

6001

Cotton Boot Covers

Fabric: 190 gsm cotton drill.

One size fits all











6002

Cotton Boot Covers with R/Tape

Fabric: 190 gsm cotton drill. Generic tape - 25mm. One size fits all



